

STEP 1

CHOOSE FLOOR OR WALL MOUNTED SETUP

WALL MOUNTS



BT8390-WFK1 BT8390-WFK2 BT8390-WFK5 BT8390-WFK6



BT8390-WFK3 BT8390-WFK4

FLOOR BASES



BT8380-FFB BT8380-AFB BT8380-FSB



BT8380-BASE BT8380-SHB

BT8380-BASE ACCESSORIES

For use with BT8380-BASE only



BT8380-CASTORS BT8380-FBFK

STEP 2

CHOOSE HEIGHT OF COLUMN

COLUMNS

BT8380-060 (0.6m)
BT8380-180 (1.8m)



COLUMN EXTENSION KIT



BT8380-EXTV

COLUMNS

WALL TIE-BACK



BT8380-WTB

FALSE FLOOR TRIM



BT8380-FFT




BT8380-060 (0.6m) BT8380-180 (1.8m)

STEP 3

CHOOSE LENGTH OF MOUNTING RAIL

MOUNTING RAILS



RAIL EXTENSION KIT




BT8390-EXT

ANGLE CONNECTOR



BT8390-AAC

MOUNTING RAILS



JOINING KIT



BT8380-JPK BT8380-JPT

ADAPTOR KIT




BT8390-ADP

STEP 4

CHOOSE SCREEN INTERFACE KIT

SCREEN INTERFACE ARMS



BT8390-VESA200F BT8390-VESA200T



BT8390-VESA400F BT8390-VESA400T



BT8390-VESA400MAF BT8390-VESA400MAP



BT8390-VESA600F BT8390-VESA800F BT8390-VESA1200F

STEP 5 ADD ACCESSORIES



BT7884



BT7032 BT7033



BT8390-SA BT7863 BT7866 BT7871-78

STEP 1

CHOOSE A SYSTEM 2 CEILING, WALL OR FLOOR MOUNT

CEILING MOUNTS



SPECIALIST MOUNTS



WALL MOUNTS



FLOOR MOUNTS



STEP 2

CHOOSE LENGTH OF SYSTEM 2 POLE

Ø50MM POLES

STANDARD
 BT7850-050 (0.5m)
 BT7850-100 (1m)
 BT7850-150 (1.5m)
 BT7850-200 (2m)
 BT7850-300 (3m)

HEAVY DUTY*
 BT7853-200 (2m)
 BT7853-300 (3m)
*Only available in Black

POLE RING



POLE JOINERS



Ø50MM POLES

STANDARD
 BT7850-050 (0.5m)
 BT7850-100 (1m)
 BT7850-150 (1.5m)
 BT7850-200 (2m)
 BT7850-300 (3m)

HEAVY DUTY*
 BT7853-200 (2m)
 BT7853-300 (3m)
*Only available in Black

POLE RING



STEP 3

CHOOSE LENGTH OF SYSTEM X MOUNTING RAIL

Ø50MM ACCESSORY COLLARS



COLLAR MOUNTING BRACKET



MOUNTING RAILS




RAIL EXTENSION KIT



ANGLE CONNECTOR



MOUNTING RAILS



STEP 4

CHOOSE A SYSTEM X INTERFACE KIT & ACCESSORY

ACCESSORIES



ACCESSORY ARM



SCREEN INTERFACE ARMS

